

DALLUGE TOOLS

TRADESMAN TOUGH

E-Z HANDLE REPLACEMENT INSTRUCTIONS FOR WEDGED TOOLS: Always follow proper assembly instructions.

- 1 Saw off old handle below eye.



- 2 Drive out old eye section using blunt punch or chisel.



- 3 Check fit of handle to eye of tool. Re-size handle with wood rasp to fit eye of tool if necessary.



- 4 Lubricate new handle eye with linseed oil and drive into tool to shoulder.



- 5 Drive wood wedge firmly into slot and saw off excess material at top of eye.



- 6 Drive steel wedges in diagonally.

